

Step #1) Turn off turn off main power, turn off machine. Take your AB Panelview 1000, out of your machine.

Step #2) Gently remove the old touchscreen, use an exacto knife to slide underneath the overlay and slowly unpeel the overlay and touch screen.

Step #3) Take out our touchscreen overlay from the Monitech box, layout the products as shown.

Step #4) Connect the multi colored cable to the connector on the replacement touchscreen.



Step #5) Connect the ribbon cables off your replacement touchscreen, to the computer of your AB Panelview 1000.



Step #6) Do not remove any sticker for the overlay or predictive film. Power on your AB Panelview 1000, test if the touchscreen is responsive.

Step #7) Stick the overlay onto your AB Panelview 1000.

For Technical Support, Call 1-877-493-6105

Support@Monitech.com

MONITECH

20 Howard Place Kitchener, Ontario N2K 4Z4 CANADA

519.725.222

www.monitech.com