


LED BACKLIGHT REPLACEMENT FOR:
PROFACE MODEL #: 3080021-10
LCD PART#: SHARP LQ121S1DG21
INVERTER #: CXA-P1212B-WJL




1.Power off the Proface HMI. Take it out of your machine.

2.Take the back cover off and open the assembly to get to the LCD panel.




3. Unscrew the CCFL backlight out of the LCD Panel. Take the CCFL bulbs out of the housing. Take out the inverter board. Then stick the Monitech LEDs into the housing. Then mount the back light cover back in.





4.Attached the inverter cable into our inverter board and stick the inverter boards into safe no conductive places on the assembly.



5.Assemble everything back together. Then power up your Proface HMI.

Keep your AB PanelView's up and running!



Replacement: LCD's, Backlight's, Keypad's & Touchscreen's for the whole 550 line.



Replacement: LCD's, Backlight's, Keypad's & Touchscreen's for the whole 600 line.



Replacement: LCD's, Backlight's, Keypad's & Touchscreen's for the whole 900 line.



Replacement: LCD's, Backlight's, Keypad's & Touchscreen's for the whole 1000 line.



Replacement: CRT TO LCD
CONVERSION's, Backlight's, Keypad's &
Touchscreen's for the whole 1200 line.



Replacement: CRT TO LCD
CONVERSION's, Backlight's, Keypad's &
Touchscreen's for the whole 1400 line.

For Technical Support, Call
1-877-493-6105
Support@Monitech.com



20 Howard Place
Kitchener, Ontario N2K 4Z4
CANADA 519.725.222
www.monitech.com